

26134 – 10FT Octagon Sandpit

Assembly Instructions

Components:	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty		Tools Required
	A.	Side Panel	8	B.	Ledge	4	C.	Fixing Plate	16		Screwdriver
	D.	70mm Screws	32	E.	40mm Screws	48					

1. Check you have all the components.	2. Position two of part A as shown.	3. Position one of part C over the join as shown.	4. Screw part C into place using 2x 70mm & 2x 40mm screws as indicated.
5. Position one of part C over the join on the bottom as shown. Screw into place using 2x 70mm & 2x 40mm screws as indicated.	6. Repeat steps 3-5 to create an octagon as shown.	7. Position one of part B as shown, ensuring part C is covered. Screw into place through the pre-drilled holes using 4x 40mm screws.	8. Repeat step 7 with remaining parts B. 9. Done. Enjoy.