










COMPONENTS

- 1 x wood part – A;
- 1 x wood part – C;
- 1 x wood part – C1;
- 2 x wood part – D;
- 2 x wood part – E (left and right);
- 2 x wood part – F (left and right);
- 2 x wood part – G;
- 1 x bag of screws 4,0x50(24pcs);
- 1 x bag of screws 4,0x70(17pcs);



		
1. Screw through F parts into D using 4,0x70 screws.	2. Screw through G into E and F parts using 4,0x50 screws.	3. Screw through E parts into D using 4,0x70 screws.
		We would love to hear your feedback on our assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al: alastair@cosydirect.com Email us your  Ideas ideas@cosydirect.com
4. Screw A part into frame using 4,0x50 screws.	5. Screw C and C1 together. Then screw through C into legs. Use 4,0x70 screws.	