




21105 - Role Play Outdoor Shop

Assembly Instructions

Components:											
Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty
A.	Folding Walls	1	B.	Gates	2	C.	Roof	1	D.	Packet of Screws	1
    1. Check that you have all of your parts and grab a screwdriver. 2. Unfold your 4 walls to make a 'U' shape. 3. Place your roof over this assembly and screw into the walls through the roof. 4. Ensure that the roof sits neatly OVER each of the walls. 5. Position the gates slightly raised off the ground and fix the hinges into the walls where indicated. 6. Repeat this for all 4 hinges.     Step 4. Step 5. Step 5. Enjoy!											

Email us your  Bright Ideas
ideas@cosydirect.com

We would love to hear your feedback on our assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com