

23152 & 23508 - Cosy Writing Stations

Assembly Instructions

Components:	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty
	A.	Hanging Wall	1	B.	Feet	2	C.	Screws	4



1. Remove the feet that come pre-attached to the backboard.
2. Position the feet at either side of the unit as shown and screw in place.
3. Enjoy!

Email us your  Bright Ideas
ideas@cosydirect.com

We would love to hear your feedback on our assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com