




26196



Fairy Child Door

Included door frame, door (pre assembled)
Stand. Screws.




Begin by securing the door frame to the base from underneath with screws. Two per side of doorframe.

Attach the door there are 3 screws per hinge, and there are 2 hinges/



Attach the door handles to the door there is a pre drilled hole for a bolt bar which the two handles twist on too to secure. The completed door should look like the image on the right.



Email us your  Bright Ideas
ideas@cosydirect.com

We would love to hear your feedback on our assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com