


# 26581 & 29000 - Loose Parts Bunker & Cosy Crate




## Assembly Instructions

### Components:


Bag of screws x 1, 1x Rear wall, 2x side walls, 1x front wall.



1. Lay out all of your parts and make sure you have each component and a screwdriver.



2. Screw one of the shorter, side walls to the large rear wall panel. Screw through the side. Repeat for the other side.



3. Screw the front to the connected 3 other panels, one again screwing through the sides.



8. Enjoy!

Email us your  Bright Ideas  
ideas@cosydirect.com

We would love to hear your feedback on our assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com

Please note: This product is not designed to be repeatedly moved. Damage may be caused if handled incorrectly. If you are worried, you can strengthen this product by reinforcing it by screwing extra screws through the skeleton of the framework.