

31889 – Bigger Bike Shed

Assembly Instructions

Components:												
Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	
A.	Base	1	B.	Side Wall	2	C.	Back Wall	1	D.	Roof	1	
E.	Front Wall	2	F.	Door	2	G.	Hinge	4	H.	Bag of Screws		

1. Check you have all the components.		2. Position a side wall, back wall and base as shown. Screw into place.		3. Position the second side wall as shown and repeat step 2.		4. Position front wall as shown. Screw into place from the inside.	
5. Position roof as shown. Screw into place through the wall into the roof.		6. Position door as shown. Fix in place using the hinges provided.		7. Repeat step 6 with the remaining door.		8. Enjoy.	

Shed Care Instructions & Warranty Information

Congratulations! We hope you enjoy your Cosy storage shed :). To get the most out your shed, there are a few things you need to do make sure your shed lasts as long as possible:

Safety Information

For safety please ensure that your storage shed is sited on solid, stable, flat, hard standing ground. We also recommend that you site it against a wall, building or fence and secure it in place to reduce any chance of severe weather tipping or damaging the shed.

To help avoid falls, ensure children do not climb on the shelves, clamber up the shed sides or swing on the doors. Ensure its use is always well supervised.

Warranty & Care instructions

Our 2 year shed warranty covers against general timber rot and decay - It does not cover against timber splits or warping as these can occur naturally over time.

Please note: Sheds can be prone to changes in appearance and shape, especially in extreme weather conditions. These will not affect the structural integrity of the product, this is a natural feature and not covered in the warranty.

To ensure that your product warranty is valid, it is critical that you follow these procedures:

- Site the product on hard, level ground with good drainage such as tarmac, concrete or paving.
- If you are fixing your shed to a wall or fence; please make sure that any holes made are treated, that there is a gap left at the back for water to drain off the roof and that you don't pierce the felted areas.
- Heavy items should be stored on the bottom level of the shed to keep the centre of mass low. It also means that heavy items are less likely to fall on top of children.
- Ensure that the shed is not positioned under or next to trees, bushes or foliage.
- Do not store wet items in the sheds without appropriate ventilation or moisture control.
- The treatment on the shed MUST be re-applied every year. You can do this by purchasing a good non-toxic stain and applying it liberally to the outer panels of your shed.
- If the blackboard paint begins to deteriorate, you can refresh this by sanding off the spoiled paint and reapplying over this area. You can purchase this paint directly from Cosy or any respectable hardware retailer.
- For any self assembly sheds, ensure that it is fully and correctly assembled. Any damage or issues caused by incorrect assembly are not covered against.
- Ensure that at the end of each session, the doors are completely closed with all latches used where applicable to help lessen any warping over time.
- During periods of high wind, each setting should consider whether a shed needs additional securing and also whether an outdoor space is safe for children to play outside.
- If the risk of fire is raising a concern we would recommend using fire retardant paint or varnish on your shed.

****NOTE:** Please be sure that any stains or paints used are child-friendly and non-toxic.

Your thoughts

If you have any great photos of how you use your shed, we would be delighted to see them! Please email these or any ideas you have to ideas@cosydirect.com and you may see them in our next catalogue!

This information is only provided as guidance. You should always satisfy yourself the product is completely safe to use in your environment with a full safety assessment.

*Cosy, The Chocolate Factory, Siddals Road, Derby, United Kingdom, DE1 2QD
Tel: +44 (0)1332 370152 Fax: +44 (0)1332 639924*

Email us your

ideas@cosydirect.com

We would love to hear your feedback on our assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com

