














32416 – Low Outdoor Shelving

Assembly Instructions

Components:	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty
	A.	Side Panel	2	B.	Shelf	2	C.	Back Panel	2	D.	Roof	1
	E.	70mm Screws	8	F.	40mm Screws	10	G.	20mm Screws	12			

					
1. Check you have all the components.		2. Position parts A & B as shown. Fix in place using 2x 40mm screws as indicated.		3. Fix in place using 2x 70mm screws as indicated.	
					
4. Position part A as shown. Fix in place using 2x 40mm screws as indicated.		5. Fix in place using 2x 70mm screws as indicated.		6. Position part B as shown. Fix in place using 2x 40mm & 2X 70mm screws as indicated.	
				7. Fix in place using 2x 40mm & 2X 70mm screws as indicated.	

			
8. Carefully turn the unit onto its side as shown.	9. Position part C as shown. Fix in place using 6x 20mm screws as indicated.	10. Position part C as shown. Fix in place using 6x 20mm screws as indicated.	11. Carefully turn the unit back onto its feet as shown.
			
12. Position part D as shown. Fix in place using 1x 40mm screws as indicated.	13. Fix in place using 1x 40mm screws as indicated.	14. Done.	15. Enjoy. Display items not included.