










A		M8 x 160	8
B		M8 x 120	24
C		M8	32
D			32
E			32







3



4



5

Tighten all the bolts


6

Fully insert end caps to cover the nuts & washers.



7


Done. Enjoy






User Instructions:

- These Monkey Bars are recommended for use of children between the ages of 5-11 years old. Adult supervision required.
- We advise this product is sited on a flat level surface suitable safe surface.
- Before the start of each play session check that all the fixings are tight.
- Check the Monkey Bars frequently for breaks and hazards such as crack and splinters. (Wood is a natural product and susceptible to splitting due to damp & dry conditions)
- Report any safety problems to COSY immediately.
- The treatment on the Monkey Bars MUST be re-applied 6-12 months to help prolong its life.
- Please be sure that any stains or paints used are child-friendly and non-toxic.



The monkey bars have a free fall height of 1,45 m



The monkey bars require 1,5 m of falling space on all sides

WARNING:

Not suitable for children under 36 months due to small parts.
Choking Hazard.