









47310 – Mini Grass Climbing Crest

Assembly Instructions

Components:	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty
	A.	Climbing Panel	1	B.	Step Panel	1	C.	Apex Block	2	D.	Long Cross Bar	2
	E.	Half Round Post	1	F.	90mm Screws	20						

							
1. Check you have all the components.		2. Position parts A & B as shown.		3. Position one of part C as shown. Screw into place through the pre-drilled holes in the direction indicated (4x90mm screws)			
							
4. Position one of part C as shown. Screw into place through the pre-drilled holes in the direction indicated (4x90mm screws)		5. Position one of part D as shown. Screw into place through the pre-drilled holes in the direction indicated (4x90mm screws)		6. Position one of part D as shown. Screw into place through the pre-drilled holes in the direction indicated (4x90mm screws)		7. Position one of part E as shown. Screw into place through the pre-drilled holes in the direction indicated (4x90mm screws)	



8. Enjoy.

Email us your Bright  Ideas
ideas@cosydirect.com

We would love to hear your feedback on our products & assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com