




48455 – Harewood Enhancement Trolley

Assembly Instructions




Components:	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	Part	Name	Qty
	A.	Leg	4	B.	Bottom Shelf	1	C.	Middle Shelf	1	D.	Top Shelf	1
	E.	Castor Wheel	2	F.	Lockable Castor Wheel	2	G.	35mm Screws	24	H.	10mm Screws	16



1. Check you have all the components.

2. Position one of part A & part B as shown.

3. Fix in place through the pre-drilled holes using 2x35mm screws.








4. Repeat step 3 using 6x35mm screws.

5. Pencil mark the legs at a height of 45cm as indicated.

6. Position the top of part C in line with pencil marks.

7. Fix in place through the pre-drilled holes using 8x35mm screws.

			
8. Position part C as shown.	9. Fix in place through the pre-drilled holes using 8x35mm screws.	10. Position one of part E as shown.	11. Fix in place through the pre-drilled holes using 3x10mm screws as indicated.
			
12. Repeat step 11 with remaining part E and both parts F using 9x10mm screws.	13. Enjoy. Display items not included.		

Email us your  Bright Ideas
ideas@cosydirect.com

We would love to hear your feedback on our products & assembly instructions. Also if you have any problems assembling our products then don't hesitate to ask Al:

alastair@cosydirect.com