




Assembly instructions

50135



49346

50136



A		7 x 50	6
B		4 x 35	36
C		4 x 16	16
D			4
E			1




1



2



3



Adult assembly required