






# 50752 – Pikler Style Triangle

## Assembly Instructions

|             |      |            |     |      |             |     |      |              |     |      |            |     |
|-------------|------|------------|-----|------|-------------|-----|------|--------------|-----|------|------------|-----|
| Components: | Part | Name       | Qty | Part | Name        | Qty | Part | Name         | Qty | Part | Name       | Qty |
|             | A.   | Apex Brace | 2   | B.   | Tall Ladder | 1   | C.   | Short Ladder | 1   | D.   | 35mm Bolts | 8   |


|                                                                                    |                                                                                            |                                                                                     |                                                                                     |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|   |          |  |  |
| <p>1. Check you have all the components.</p>                                       | <p>2. Position parts A &amp; B as shown. Fix in place using 2x35mm bolts as indicated.</p> | <p>3. Position part A as shown. Fix in place using 2x35mm bolts as indicated.</p>   | <p>4. Position part C as shown. Fix in place using 2x35mm bolts as indicated.</p>   |
|  |         |                                                                                     |                                                                                     |
| <p>5. Fix in place using 2x35mm bolts as indicated.</p>                            | <p>6. Done.</p>                                                                            |                                                                                     |                                                                                     |

## User Instructions:

- We advise this product is sited on a flat level surface, with a suitable safe surface that conforms to EN 1177:2018.
- Before the start of each play session check that all the fixings are tight.
- Check the Pikler Triangle frequently for breaks and hazards such as crack and splinters. (Wood is a natural product and susceptible to splitting due to damp & dry conditions)
- Report any safety problems to COSY immediately.
- These Pikler Triangles are recommended for the use of children from 3 years old.
- Adult supervision required at all times.

### **WARNING:**

**Not suitable for children under 36 months due to small parts.  
Choking Hazard.**



The Pikler Triangles  
have a free fall height of  
53cm

Email us your **Bright Ideas**  
ideas@cosydirect.com

