




53185 – Larger Climbing Wall

Assembly Instructions





Components:		Part	Name	Qty	Part	Name	Qty	Part	Name	Qty	Tools Required
		A.	Base	2	B.	Climbing Hold Panel	1	C.	Climbing Rung Panel	1	Electric Drill
		D.	Climbing Cut Out Panel	1	E.	Climbing Rope Panel	1	F.	Top Plank	2	
		G.	Apex Block	4	H.	80mm Screws	38	I.	50mm Screws	12	



1. Check you have all the components. Two person build.

2. Position part A on a flat level surface.

3. Position part B as shown.











4. Position part B as shown.

5. Ensure all the joints are flush and square.


6. Fix in place using 4x 80mm screws as indicated.

7. Fix in place using 4x 80mm screws as indicated.


			
8. Position part B as shown.	9. Fix in place using 4x 80mm screws as indicated.	10. Repeat steps 8-9 to the opposite side.	11. Position part F as shown.
			
12. Fix in place using 6x 50mm screws.	13. One half complete.	14. Repeat steps 2-12 using the parts as shown.	15. Two complete sections.




16. Position the two completed sections as shown.



17. Fix in place using 3x 80mm screws as indicated.




18. Fix in place using 3x 80mm screws as indicated.



19. Done.

User Instructions:


- 2 person lift and assembly.
- This product is required to be sited on a flat level surface, with a suitable safe surface that conforms to EN 1177:2018. Please check with your surface installation contractor.
- Before the start of each play session check that all the fixings are tight.
- Check the climbing wall daily after use for breaks and hazards such as crack and splinters. (Wood is a natural product and susceptible to splitting due to damp & dry conditions) Record and report any permanent defects.
- Report any safety problems to COSY immediately.
- This climbing wall is recommended for the use of children over 3 years old. Adult supervision required at all times.
- The treatment on the climbing wall MUST be re-applied 6-12 months to help prolong its life.
- Please be sure that any stains or paints used are child-friendly and non-toxic.



The climbing wall has a free fall height of 1.52m

WARNING:

**Not suitable for children under 36 months due to small parts.
Choking Hazard.**



The climbing wall requires 1.5m of falling space on all sides